

ATTENTION:

GENERAL MANAGER PARTS MANAGER
CLAIMS PERSONNEL SERVICE MANAGER

IMPORTANT - All Service Personnel Should Read and Initial




SERVICE BULLETIN

APPLICABILITY: STi Vehicles, All Model Years
SUBJECT: Towing Recommendations

NUMBER: 01-162-05
DATE: 06/28/05

INTRODUCTION

AWD Subaru vehicles with manual transmissions can be towed with all four wheels on the ground and the transmission in neutral. STi vehicles with 6 Speed Manual Transmissions can also be towed with all four wheels on the ground and the transmission in neutral. In addition, STi vehicles with 6 Speed Manual Transmissions require that the Driver's Control Center Differential (DCCD) is set in manual mode and the DCCD control dial set to the furthest rearward position.



Please refer to the owner's manual for additional important information on towing Subaru vehicles.



CAUTION: VEHICLE SERVICING PERFORMED BY UNTRAINED PERSONS COULD RESULT IN SERIOUS INJURY TO THOSE PERSONS OR TO OTHERS.

Subaru Service Bulletins are intended for use by professional technicians ONLY. They are written to inform those technicians of conditions that may occur in some vehicles, or to provide information that could assist in the proper servicing of the vehicle. Properly trained technicians have the equipment, tools, safety instructions, and know-how to do the job correctly and safely. If a condition is described, DO NOT assume that this Service Bulletin applies to your vehicle, or that your vehicle will have that condition.

