



HOT IN ON OR START
 FUSE & RELAY BOX (F/R)
 FUSE 13 10A

